


# BANNER POLE CABLE STAY KIT

## FITTING INSTRUCTIONS




This kit is designed to brace & stabilise both top and bottom banner arms for windy locations and where a larger banner is being fitted.




**Contents** This kit contains 2 sets of the following:

1 x stainless steel cable  
(with an eyebolt fitted  
at one end)



1 x individual eyebolt  
(with cable thimble fitted)



2 x cable clamps



1 x cable thimble



**Tools Required**


Drill (with a 6mm masonry bit)

7mm spanner

Cable cutter



**Instructions**



1. Once your banner poles have been fitted to the wall, mark out & then drill two 6mm diameter holes, 65mm deep into the wall & screw in the eyebolt with the cable attached into one hole, and the individual eyebolt in the other. (Ideally, these eyebolt holes should be about a banner pole's length above and the same distance on either side of the centre line).

2. Fit a cable thimble to the loop on the top banner pole & close it up.

3. Feed the cable around the cable thimble on the banner pole and then back to the wall and through the eyebolt and back on itself.

4. Fit one cable clamp loosely on the cable by the banner pole and the other at the wall end of the cable.

5. Pull the cable tight & then do both the clamps up tight, making sure not to pull the banner arm out of 'true'.

6. Cut away any excess cable.

7. Repeat steps 1 – 6 for the other banner arm.