

Post mounted Banner Pole Kits instructions

Hardware included in the kit:-

- 2 Main Poles with curved base plate
- 2 Tensioner Bars
- 2 Screw Karabiners (to hang the top Tensioner Bar from the top main pole)
- 2 Limited stretch springs (to attach the bottom Tensioner Bar to the bottom pole)

The fixing strap system is specific to the type of post, and therefore not included in the basic kit.

Tools required:-

Ideally, a Band-It style banding tool with stainless steel strapping and buckles, and a light hammer.

Alternatively, 4 Screw Band straps & the required screwdriver/spanner.

Method

1. Start at the top

Fix one of the Main Poles to the post using two straps from your chosen fixing system, ensuring the suspension loops are on the underside and the straps are securely in the notches on the base plates. (Both Main Poles are the same)

Tip:- Ideally this is a two person fix, one to hold the main pole in position & the other to do the strapping, but one person can temporarily hold the main pole in position by using a long heavy duty 'cable tie' & then cutting it off when both stainless bands are done.

2. Hang your banner

When installing the kit for the first time, the next stage is to hang the banner from the top pole. Insert one of the Tensioner Bars into the pocket along the top of the banner, and hang it from the Main Pole by the two Screw Karabiners.

3. Attach the bottom Main Pole

Insert the other Tensioner Bar in the bottom pocket of the banner and attach the bottom Main Pole using the Limited Stretch Springs.

Method:-

Take the 'U' shapes out of the spring and put them through the loops on the Tensioner Bar & the Main Pole – then push them through the middle of the spring until they lock out. The Main Pole is then positively attached to the Tensioner Bar.

4. Fix the bottom Main Pole

Using the same method as 1. above, strap the bottom Main Pole to the post. Put a slight tension on the banner (to prevent flapping) before tightening the strapping.

Tip:- To change the banner, compress the spring and squeeze one of the 'U's together & let the spring go. Then, by turning the spring round, the 'U' winds itself down the spring and comes apart.

Note:-

Do not be tempted to use nylon or lightweight strapping systems. It is the specifier's and fixer's responsibility to assess fitness for purpose of the support post and fixing system being used.

