

Swing limiter kit

This kit is designed to limit the amount the panel can swing, which is ideal for situations of high wind or strong gusts.

You decide how much wind spill to allow by setting the length of cable.

The kit contains:-

- 2 Self tapping eye bolts
- 2 galvanised cable clamps
- 400mm of stainless steel cable



Instructions

1. Drill a 5mm* hole 65mm deep into the edge of your panel, at least 50mm up from the bottom edge, and screw one of the eye bolts in.
2. Drill a 6mm hole, 65mm deep into the wall at a corresponding point, and screw the other eye bolt in.
3. Loop the cable through one of the eyes & secure with the cable clamp.
4. Loop the other end of the cable through the other eye & adjust the cable length (allowing the cable to hang loosely) before clamping it up.
5. Cut away the excess cable if there is any.

***Note:-** You must use a 6mm hole for the harder materials such as brick, stone & block, otherwise you will not be able to screw the eye in, - but we suggest a 5mm hole in the foam panel as it is a softer material and the smaller hole gives a tighter grip.

